

Furler Parts

Schaefer Marine carries all your furling needs:

Below are a listing of parts for the **CF-500, CF-700, 1100, 2100 & 3100** Furling Systems. For your convenience print the PDF Parts List for the system you are interested in and go to our parts catalog to find all your necessary pieces. The contact us at 508-995-9511, our contact your local installer. Helpful hint: Search by the part no. for quick results.

CF-500, CF 700, System 1100, System 2100, & System 3100 Furler Instructions (PDF)

System SnapFurl CF 500		
CF500 Schematic Download & Print	Description	Part No.
	Top Cap	32-026
	Extrusions	CF-500-EXT
	Feeder/Clamp	45-237
	Locking Turnbuckle Strap	53-088
Check Out Our Parts Catalog Helpful hint: Search by the part no. for quick results.		

System SnapFurl CF 700

CF700 Partslist Download & Print	<table border="1"> <thead> <tr> <th>Description</th> <th>Part No.</th> </tr> </thead> <tbody> <tr> <td>Top Cap</td> <td>32-027</td> </tr> <tr> <td>Extrusions</td> <td>CF-700-EXT</td> </tr> <tr> <td>Feeder/Clamp</td> <td>45-256</td> </tr> <tr> <td>Locking Turnbuckle Strap</td> <td>45-257</td> </tr> </tbody> </table>	Description	Part No.	Top Cap	32-027	Extrusions	CF-700-EXT	Feeder/Clamp	45-256	Locking Turnbuckle Strap	45-257
	Description	Part No.									
	Top Cap	32-027									
	Extrusions	CF-700-EXT									
	Feeder/Clamp	45-256									
Locking Turnbuckle Strap	45-257										
<p align="center"> Check Out Our Parts Catalog Helpful hint: Search by the part no. for quick results. </p>											

System 1100											
System 1100 Download & Print PDF	<table border="1"> <thead> <tr> <th>Description</th> <th>Part No.</th> </tr> </thead> <tbody> <tr> <td>Lower Bearing Assembly</td> <td>33-051-A</td> </tr> <tr> <td>Collar Bracket Plate</td> <td>45-230-A</td> </tr> <tr> <td>Torque Tube Clamp</td> <td>32-025-02</td> </tr> <tr> <td>Sail Feeder (front & back)</td> <td>45-223-M</td> </tr> </tbody> </table>	Description	Part No.	Lower Bearing Assembly	33-051-A	Collar Bracket Plate	45-230-A	Torque Tube Clamp	32-025-02	Sail Feeder (front & back)	45-223-M
	Description	Part No.									
	Lower Bearing Assembly	33-051-A									
	Collar Bracket Plate	45-230-A									
	Torque Tube Clamp	32-025-02									
Sail Feeder (front & back)	45-223-M										
<p align="center"> Check Out Our Parts Catalog Helpful hint: Search by the part no. for quick results. </p>											

System 2100

[System 2100](#)
[Download &](#)
[Print PDF](#)

Description	Part No.
Lower Bearing Assembly	33-049-A
Collar Bracket Plate	45-236-A
Torque Tube Clamp	32-024-01
Sail Feeder (front & back)	45-235-M

[Check Out Our Parts Catalog](#)

Helpful hint:
Search by the part no.
for quick results.

System 3100

[System 3100](#)
[Download &](#)
[Print PDF](#)

Description	Part No.
Lower Bearing Assembly	33-053-A
Collar Bracket Plate	45-226-A
Torque Tube Clamp	32-016-01
Sail Feeder (front & back)	45-225-M

[Check Out Our Parts Catalog](#)

Helpful hint:
Search by the part no.
for quick results.